


Haptic Feedback Evaluation Kit

User Manual



Contents

1 Introduction	1
2 System Overview	2
2.1 The Haptic Controller	3
2.2 The Haptic Grip	5
2.3 Firmware (Arduino Code)	6
3 Setup and Installation	7
3.1 Powering via USB	7
3.2 Warning on DC Power Connector	7
3.3 Installing the Arduino Drivers and Software	8
4 Intro Mode Operation	9
4.1 Navigation	9
4.2 Menu Options	9
4.2.1 Quick-Start Demo	9
4.2.2 Haptic Feedback Tutorial	10
4.2.3 Vibration Alerting Tutorial	10
4.2.4 DRV2605 Overview	10
5 Engineering Mode Operation	11
5.1 Navigation	11
5.2 True Haptics	11
5.3 Vibration Alerting	12
5.4 Debugging Feature	14
6 Development Mode Operation	16
6 Advanced Options	17
6.1 Test Points	17
6.2 External Signals / Actuators	17
6.3 Direct Access to DRV2605	18
6.4 Changing Modes of Operation	18
6.5 Editing the Arduino Code and Using the DRV2605 Arduino Library	19
6.6 Using The DRV2605 Auto Calibrate Feature	19
7 Appendices	20

1 Introduction

The Haptic Feedback Evaluation Kit is an open-source platform for experiencing haptic feedback and vibration alerting.

It serves a wide range of users. Those unfamiliar with the technology will benefit from the introductory mode and its tutorials. In addition, the kit will support engineers and product designers throughout the development process by providing an easy to use platform for hardware and software prototyping.

This document provides technical details on each section of the kit, guides for installation and usage, and advice for accessing advanced features. There is also a Quick Start Guide provided with the kit to get users up and running immediately. Additional copies of the guides and more resources, such as tutorials and example code, can be downloaded from precisionmicrodrives.com/haptic-kit/features.

It is also recommended you request a copy of the full datasheet for the DRV2605 from Texas Instruments, the haptics driver which the kit uses. A shortened datasheet is available for download online, and you can request the full copy using the link in the “Special Note” section here: www.ti.com/product/drv2605.

For additional advice about vibration motors and haptic feedback in general can be found online in the Tech Blog and App Notes sections of www.precisionmicrodrives.com.

If you experience any issues or are looking for further advice, please contact Precision Microdrives at enquiries@precisionmicrodrives.com.

ATTENTION: DO NOT use the DC power connector



Only use the USB connection to power the kit, see Section 3.2 for more details

2 System Overview

The Haptic Feedback Evaluation Kit is comprised of two main units, the Haptic Controller and the Haptic Grip.




Figure 1. Haptic Feedback Evaluation Kit System View

The Haptic Controller includes an Arduino Uno R3 with a custom designed 'shield' from Precision Microdrives. It acts as the user interface, allowing the user to navigate through the menu systems on the OLED screen using the capacitive touch buttons. It also houses the hardware used to drive the motors, including a DRV2605 from Texas Instruments for haptic feedback (Section 5.2) and a MOSFET for simple vibration alerting (Section 5.3).




Figure 2. The Haptic Controller

The Haptic Grip contains the actuators that play the various vibration patterns sent by the Haptic Controller. The two are connected by a ribbon cable that carries the power, drive, and motor selection signals. With 3 different eccentric rotating mass vibration motors and 1 linear resonant actuator, the grip houses actuators from our high performance Precision Haptic™ range.



Figure 3. The Haptic Grip

2.1 The Haptic Controller

Arduino is an open source development platform for electronics which has many different boards available, the Uno R3 board is based on an Atmel ATmega328 microcontroller. Although the term ‘Arduino’ refers to the project as a whole, it is colloquially used to refer to the specific board you are using – a convention we will use in this documentation.

The Arduino allows you to easily program the microcontroller through your computer using software that you can download online, see Section 3 for installation instructions. Due to its simplicity and versatility it is extremely popular with hobbyists and professionals who use it for prototyping and other projects. As a result there is a very active online community where you can find advice and details about the boards.

The stackable headers of the Arduino provide access to various pins on the board, PCBs can be designed to fit directly onto these headers and are known as ‘shields’.

Arduino shields are often created for a specific purpose such as WIFI connectivity or SD card readers, our Haptic Shield works with the provided firmware (code for the microcontroller) to provide a user interface and drive the vibration actuators. This is achieved by including several components, the main ones are listed below.

- **Capacitive Touch Buttons**

There are 6 capacitive touch buttons that are used to provide the input to the Haptic Controller. There are slight differences in their function depending on the mode of operation (Sections 4 & 5). From the top left, working clockwise, the buttons are: **Back** button, **Play** button, **PMD** button, **Right** button, **Select** button, and **Left** button. The buttons themselves rely on MPR121 touch driver which communicates over the I2C communications bus.



Figure 4. Capacitive Touch Buttons

- **Screen**

An OLED screen provides visual cues to the user about the current status of the controller. The menu system is displayed on screen and navigated using the capacitive touch buttons. Depending on the mode of operation the screen may display information about the effect being played, output actuator, or walk through tutorials. There are 8 lines of orange LEDs at the top and 24 lines of blue LEDs below. It is controlled via SPI.




Figure 5. OLED Screen

- **DRV2605**

This is the haptic driver, produced by Texas Instruments. It contains over 123 different haptic effects, with royalty free licensing from Immersion, and can drive both ERMs and LRAs. It has a range of advanced features including overdrive and active braking for haptic effects, and auto-resonance tracking for LRAs. It is controlled by the Arduino via I2C communications bus.



Figure 6. DRV2605 Haptic Driver

- **MOSFET**

A simple MOSFET is used to drive vibration alerting patterns on the vibration motors. It uses a simple PWM signal from the Arduino, where varying the duty cycle controls the speed and vibration strength of the ERM. The change in duty cycle is handled by the firmware in the Arduino and you can build your own patterns in the Engineering Mode (Section 5). **The LRA in the Haptic Grip cannot be driven by the MOSFET.**




Figure 7. MOSFET

- **Linear Resonant Actuator**

Touchscreens are a common application for haptic feedback, where the tactile feel of pressing buttons is lost. Naturally we have included an LRA (C10-100) on the Haptic Shield to provide the user with haptic confirmation of their presses on the capacitive touch surface. It too is driven by the DRV2605 and will give different effects for different confirmations (which can be changed in the software).




Figure 8. C10-100 Linear Resonant Actuator

- **Metal Base**

The Haptic Controller is finished with a metal base that supports the Arduino and Haptic Shield. Mounting holes are positioned to fit the Arduino, which use rubber mounts to improve mechanical isolation between metal base and the Arduino with shield. This helps reduce noise from the LRA vibrating. There is also a clip section to help secure the ribbon cable to provide strain relief and stop the connector from being damaged through mishandling.



Figure 9. Metal Base Section

2.2 The Haptic Grip

The Haptic Grip is a small ergonomic unit that houses the vibrating actuators. Using a separate unit has several benefits:

- Allows us to easily include multiple actuators.
- Has a form factor that is representative of many end applications
- Helps separate the haptic effect being played from the capacitive buttons on the Haptic Controller by the LRA
- Allows a user to easily share their haptic experience with a colleague by using the Haptic Controller and handing the Haptic Grip to someone else.

The Haptic Grip contains a small PCB and has two leaded ERMs mounted directly into the base, all of which can be accessed by peeling back the black rubber section from the red metal section.



Figure 10. Haptic Grip Peeled Back

There is a single quad channel multiplexer / demultiplexer IC that handles the actuator selection signals from the Haptic Controller, reducing the need for excessive cabling. To aid debugging, there is an LED for each actuator which is lit when that actuator is selected by the Haptic Controller in addition to topside connection pads for each motor.

There are 3 eccentric rotating mass vibration motors and 1 linear resonant actuator:





Model Number	Type	Typical Normalised Amplitude	Rated / Resonant Vibration Frequency	Rated Voltage	Image	Full Datasheet
305-000	ERM	0.8 G	125 Hz (rated)	1.3 V		Download 305-000 Datasheet
306-109	ERM	3.5 G	200 Hz (rated)	3 V		Download 306-109 Datasheet
308-102	ERM	5.5 G	300 Hz (rated)	4.5 V		Download 308-102 Datasheet
C10-100	LRA	1.4 G	175 Hz (resonant)	2 V (RMS)		Download C10-100 Datasheet

Figure 11. Haptic Grip Actuator Table

2.3 Firmware (Arduino Code)

An important part of the Haptic Feedback Evaluation Kit is the firmware code that is loaded into the Arduino. There are 2 modes of operation provided with the kit (Sections 4 & 5), it is possible to change between these modes as many times as you like. This is achieved by following the steps in Section 7.4.

The firmware handles several important tasks that tie the separate sections of the system together:

- Building the menu system for user guidance
- Displaying text and images on the OLED screen
- Receiving input from the user through capacitive touch buttons
- Making logical decisions based on the menu system and user input
- Sending motor selection code to multiplexer
- Interfacing with the DRV2605 or MOSFET to play haptic effects or vibration alerting patterns

As the firmware is open source and accessible through the Arduino software environment, it is possible to use the Haptic Feedback Evaluation Kit as a development platform for prototyping units. Arduino uses its own programming language based on Wiring, which is essentially a set of C/C++ functions called from the code. Therefore anyone familiar with C/C++ languages, or the Processing or Wiring projects, should find Arduino development an easy transition. Libraries and tutorials are provided at precisionmicrodrives.com/haptic-kit.

3 Setup and Installation

The Haptic Feedback Evaluation Kit is designed to operate 'out-the-box' allowing users to immediately experience haptic feedback. Arduinos are powered using either the USB socket or DC power socket, both located at the bottom of the Haptic Controller. **Do not use the DC power socket**, see Section 3.2 below.

3.1 Powering via USB

The Arduino uses a USB type B socket. This can be used to provide power to the kit as well as accessing the firmware on the Arduino (see Section 3.4 for installation) and debug information. The USB port can be plugged into a port on a computer or to a USB wall charger.

To provide enough current when using a USB port on a computer the Arduino drivers must be installed. The default current allocation to a USB device is 100 mA, with the drivers installed the Arduino is able to negotiate up to 500 mA. Please note that some PCs use the same USB bus to power several USB ports, therefore you should unplug any other USB devices unless you are sure enough current is being supplied to the kit.

To provide enough current when connecting to a USB wall charger double check the rating of the USB wall charger is no less than 500 mA.

3.2 Warning on DC Power Connector

ATTENTION: DO NOT use the DC power connector!



The Arduino includes a DC power socket which is designed to offer a choice in power supply. However it is not possible to use the DC power socket with the Haptic Shield. Using the DC power risks immediately damaging the analogue switch.

Only use the USB connection to power the Haptic Feedback Evaluation Kit.

3.3 Installing the Arduino Drivers and Software

The installation process for the Arduino is simple, however it is updated periodically through the Arduino website. We recommend following the most recent steps by visiting the Arduino 'Getting Started' page:

arduino.cc/en/Guide/HomePage

The link above will allow you to:

- Install the Arduino Uno R3 drivers
- Install the Arduino coding IDE (recommended but only required if you intend to switch firmware modes, Section 6.4)

4 Intro Mode Operation

There are three firmware modes available, all of which are available for download from precisionmicrodrives.com/haptic-kit/codes.

The “**Intro Mode**” is the default mode of operation and is loaded onto the kit prior to shipping. It is aimed at non-technical users who are unfamiliar with haptic feedback and vibration alerting. It consists of 4 different tutorials (more information in Section 4.2:

- **Quick-Start Demo** for a fast explanation of haptic feedback and vibration alerting
- **Haptic Feedback Tutorial**
- **Vibration Alerting Tutorial**
- **DRV2605 Overview** for a look at the Texas Instruments DRV2605 features

It is recommended you print / load a copy of the “Haptic Feedback vs Vibration Alerting” crib sheet (see appendix D) to accompany the tutorials. It is especially useful for sharing exactly what is required for implementing each technology.

You can switch to the “**Engineering Mode**” firmware to test all the available features of the kit by loading it onto the Arduino, instructions in Section 6.4.

4.1 Navigation

There is a single top-level menu that includes the four demonstrations / tutorials. To navigate between these menu options, use the **left** and **right** buttons. To enter a menu option, press **select**.

Although they have different content, the menu options all work in the same way. Press **right** to navigate forward through the slides. At specific points you will be prompted to press the **play** button to experience different effects. To repeat the effects, press **play** again.

You can exit the current demo / tutorial at any point and return to the top menu by pressing the **back** button. In the Intro Mode the **PMD** button is not used.

4.2 Menu Options

4.2.1 Quick-Start Demo

The Quick-Start Demo is a short overview that allows the user to experience vibration alerting first, followed by haptic feedback. The demonstration is very basic and is suitable for introducing the idea of adding vibration technology to a device, useful for sharing the concept with non-technical colleagues.

4.2.2 Haptic Feedback Tutorial

The Haptic Feedback Tutorial is designed to give the user an overview of haptic effects with example vibration patterns. It also includes an example application of a car parking sensor, showing how different haptic vibration patterns can be used to convey the same information.

The tutorial serves as a good introduction to haptic feedback and can be used by non-technical persons looking to develop their knowledge in the area. It is also useful for engineers and product developers to experience different haptic effects and get a quick overview of the capabilities of the DRV2605 and Precision Haptic™ actuators.

4.2.3 Vibration Alerting Tutorial

The Vibration Alerting Tutorial gives several examples of vibration alerting waveforms. It highlights how a vibration alerting waveform can be used to alert the user to events, and often represent warnings.

When used in conjunction with the Haptic Feedback Tutorial the user should be able to understand the difference in the two technologies and recognise if their design would benefit from advanced haptic feedback or the simpler vibration alerting. It is therefore useful for both non-technical and technical users.

4.2.4 DRV2605 Overview

All haptic effects are played by a special haptic feedback driver chip from Texas Instruments, the DRV2605. This demonstration covers some of the advanced features of the chip, and lets users directly experience how they improve the vibration output.

It is shorter than the other tutorials and serves as a precursor to downloading the 'Engineering Firmware'. For this reason it is of most use to engineers who intend to continue development with the kit and experiment with the DRV2605 itself.

5 Engineering Mode Operation

To test all the available functions of the kit, the Engineering Mode can be loaded onto the kit once downloaded, see Section 7.4 for instructions.

It is aimed at technical users and engineers who are ready to start experimenting with haptic feedback and vibration alerting. It is also required to use some of the advanced features, such as external actuator connection, and further development.

It is recommended you print / load a copy of the “True Haptics Menu Map” and the “Effect Library and Finder” sheet (see appendices E and F, and online) to accompany this mode. It is especially useful for navigating to specific effects.

5.1 Navigation

The menu system is based on a hierarchy where you move left and right through the menu options (presented as tabs) and press **select** to enter the selected menu option. The **back** button moves you up a menu level and holding it down returns you to the top level.

In the top menu you can select between experiencing the ‘True Haptic’ waveforms or building your own ‘Vibration Altering’ pattern.

In ‘Engineering Mode’ the **PMD** button cycles through the output actuators.

5.2 True Haptics

Here you can access all of the haptic waveforms and libraries stored on the DRV2605. The effects are grouped into different categories and can be played on each of the actuators.

The screen shows the current status including the Menu Options, current Effect Library, the selected Effect, and the output Motor:




Figure 12. True Haptic Menu Layout

The tabs at the top will show menu options until you navigate deep enough to the effects. Effects are displayed differently, and are identified by the effect number. For example, in the menu level “True Haptics -> Clicks ->

Double” there are 3 further menu options; Strong, Medium, and Sharp. Selecting the menu option “Medium” displays 6 different effects, Medium 1 to Medium 6.




Figure 13. Menu Option Tab vs Effect Option Tab

There is an effect loaded and ready to play at all times, by default this is Effect 1, Library 1, on Motor 305-000. Pressing play will send the effect to the selected motor in the Haptic Grip.

To play an effect press the **play** button at any point. Note if pressing the **play** button at any menu level will play the loaded effect, unless your menu is at a new effect. In this case the kit will play the new effect shown on screen instead of the previous one loaded.

To change the effect use the **left**, **right**, and **select** buttons to navigate to the desired new effect and press the **play** or **select** button.

To change the library navigate to the Library Menu Option, the last tab in True Haptics, and press select. Use **left** and **right** to select the new library and press **back** once chosen. It is possible to press **play** when scrolling through the libraries, making it easy to compare the difference between each library.

To change the output actuator cycle through the ERMs and LRA by pressing the **PMD** button.

5.3 Vibration Alerting

This section enables you to build different vibration alerting waveforms and play them through any of the ERMs located in the Haptic Grip. The waveforms are created by varying the PWM duty cycle on the Arduino through the MOSFET. As a result, the DRV2605 is not used and the C10-100 LRA is not supported for vibration alerting.

Vibration alerting output is made from four simple variables which can all be edited. The output is then repeated until the user stops it. The screen shows the current status including the menu options, output motor and the four variables.




Figure 14. Vibration Alerting Menu

1. **Waveform**

This is the shape of the voltage input to the ERM. There are 4 different waveforms available – square (Sqr.), sine (Sin.), Triangle (Tri.), and Sawtooth (Saw.). As the drive voltage is DC and the polarity is not switched, the sine waveform is actually a half sine wave:




Figure 15. Vibration Alerting Waveforms

2. **Power**

The power represents the peak strength and is a percentage of the motor’s rated voltage, selectable in 10% increments

3. **On Time**

The on time determines the length of time the waveform is played across.

4. **Off Time**

The off time controls the rest period between each wave cycle. Increasing the off time reduces the frequency of alerts, whereas setting it to zero immediately restarts the vibration waveform.

This image shows how the four variables affect the vibration output:




Figure 16. Vibration Alerting Variables

To change the vibration alert change the desired variable by navigating to its menu option and press **select**. Then use the **left** and **right** buttons to change the value, press **back** or **select** to confirm the change.

To play the waveform once the four variables have been set, press the **play** button.

To change the output actuator press the **PMD** button, cycling to the desired ERM.

5.4 Debugging Feature

The Engineering Firmware includes an additional debug feature to help you understand the status of the kit. Selected information can be passed up the USB connection to a computer running the Arduino software. Therefore, this mode can only be used when the kit is powered through the computer's USB port rather than a standalone USB power socket.

To enter the debug mode, you will need to navigate to the top level menu by holding down the **back** button, this should be confirmed with a long vibrate on the Haptic Controller. Once at the top level hold down the **PMD** button to enter the Debug Mode.

You will also need to open the Serial Monitor in the Arduino software. This is found in the Tools menu, or you can use the keyboard shortcut **Ctrl + Shift + M**. Opening the Serial Monitor should restart the program, so by default you will find yourself at the top level and ready to enter the debug mode.




Figure 17. Arduino Serial Monitor

The screen on the Haptic Controller will present you with three options, each of which will print different information on the serial monitor window.

1. Dump Settings

Prints the values stored in the DRV2605 EEPROM. These values are the motor calibrations and a bitmask for which motors are calibrated. It appears as a "Mem Dump" followed by a single hexadecimal byte in the serial monitor.

2. Reset Auto Calibration

Wipes the motor calibration values stored in the EEPROM. This means none of the motors are seen as calibrated and the kit will re-run the auto calibration when each motor is selected. This is confirmed by printing the status byte, "AutoCal success" and the new auto cal values on the serial monitor.

3. Firmware Information

Prints the current version of the firmware on the serial monitor. This can be edited in the debug_defs.h file if creating your own revisions of the program.

6 Development Mode Operation

The Development Mode is a bare-bones sketch that allows you to build your own working prototype using the Haptic Feedback Evaluation Kit.

It handles setting up the DRV2605 and Arduino, such as configuring the pins and initialising the I2C bus, but the main section of code can be edited to behave as you require. There are also multiple functions built in to the DRV2605 library to handle common functions, such as playing a haptic effect.

The Haptic Shield can be installed into the Arduino, or can be connected to separately to provide access to the available Arduino pins. There are several example applications that demonstrate using the Development Mode online at precisionmicrodrives.com/haptic-kit/tutorials.

The DRV2605 Library and Pin Mapping documents (see appendix G) are also good resources, as they describes the functions available for use in the Development Mode and the pins required by different components on the Haptic Shield. These can both be downloaded from precisionmicrodrives.com/haptic-kit/documents.

7 Advanced Options

The kit has a number of additional features to aid understanding of key concepts and assist further development and prototyping.

7.1 Test Points

Several SMD test points are available across the Haptic Controller and Haptic Grip to view various signals on an oscilloscope or connect to other instrumentation. It is also possible to use them as connection points for input signals or to connect an external actuator. These include:

- **EN**

Connects to DRV pin A1 “EN” and Arduino pin D4. The EN (enable) pin switches the DRV2605 between ‘active’ and a low-power ‘standby’ state.

- **PWM**

Connects to DRV pin B1 “IN/TRIG” and Arduino pin D9. The IN/TRIG pin is one of the most versatile on the DRV2605. Depending on the register values (accessed via I2C), the signal sent to this pin can put the DRV2605 into a number of different operation modes. This is best explained in the DRV2605 datasheet, and this test point can either be used as an input or to monitor the signal sent by Arduino.

- **GND**

Connects to DRV pin B3 “GND” and the ground throughout the shield and Arduino. It can be used to set a common ground between the Haptic Controller and instrumentation.

OUT+ and OUT-

Connects to DRV pins A3 “OUT+” and C3 “OUT-“. These can be used to either measure the signal being sent to the selected output actuator, drive an external actuator, or both. See the instructions below.

7.2 External Signals / Actuators

To read the signal sent to an actuator it is best to use an oscilloscope. The following is taken from the DRV2605 datasheet as is recommended for reading drive signals:




Figure 18. External Actuator Oscilloscope Connection

To connect an external actuator unplug the grey ribbon cable from the haptic controller, either at the haptic grip end or the haptic controller end. Then attach your new connector to the appropriate OUT+ and OUT- test points, it is recommended to use spring connectors.

7.3 Direct Access to DRV2605

There are two ways to directly access the DRV2605.

The easiest method is to use the Arduino as it is already connected. Simply edit the Arduino sketch or create your own to interface with the DRV2605 as you wish. To help, Section 6.5 discusses how to edit the Arduino code and access the Arduino library for the DRV2605 from Precision Microdrives.

Alternatively the Haptic Shield can be removed from the Haptic Controller and plugged into a breadboard or connected to via the pins on the underside. This method allows you to access the pins on the Arduino for connecting your own inputs or use a different processor / host to interface with the DRV2605.

Used in conjunction with the external actuator connection it is possible to mount an ERM or LRA in a prototype mechanical system, e.g. touchscreen or handheld mould, and continue to use the DRV2605 for driving the actuator.

7.4 Changing Modes of Operation

You can change between the two modes of operation (Intro Mode and Engineering Mode) as many times as you wish. This is done by writing a new program to the Arduino. The kit has the Intro Mode loaded by default, a new program can be transferred (written) to the Arduino through the USB connection by the Arduino IDE.

To change between modes of operation, you will need to download additional resources.

The first is the Arduino software environment. It is open-source, free, and available on Windows, Mac OS X, and Linux. See Section 3.4 for installation of the Arduino drivers and software.

The second is the program files for the different modes of operation. We provide all the source code for the IntroMode and Engineering Mode with further coding examples, including a library for the DRV2605, at

precisionmicrodrives.com/haptic-kit. Download the 'Modes of Operation' files and extract them to a folder on your hard drive.

To upload a new code, open the desired .ino file in the folder you have just extracted it to. Once the Arduino IDE opens with the code, press the upload button.

7.5 Editing the Arduino Code and Using the DRV2605 Arduino Library

As an added benefit of the Haptic Feedback Evaluation Kit you now own an Arduino! You can use it as a standalone development tool for other projects, or preferably use it to create a prototype haptic feedback device. The Arduino Uno R3 is based on the ATmega328 processor, which you can use in your final design.

To aid prototyping with the DRV2605 there is a library written by Precision Microdrives available for download at precisionmicrodrives.com/haptic-kit/codes. This includes a series of pre-built functions that take advantage of the DRV2605 features. See Appendix E for a list of available functions.

It is recommended you use the series of examples precisionmicrodrives.com/haptic-kit/tutorials which show different basic skeleton codes demonstrating how to use the functions.

For general errors and problems using the Arduino it is best to seek advice from the Arduino community at www.arduino.cc. If you require any help specifically using the DRV2605 Arduino Library please contact us at enquiries@precisionmicrodrives.com.

7.6 Using the DRV2605 Auto Calibrate Feature

The DRV2605 has many additional features to improve haptic effects, such as overdrive and active braking or auto resonance detection for LRAs. Auto calibration is another feature provided by the DRV2605 to improve the haptic performance.

The auto calibration process monitors the back-EMF of the actuator and uses the results to adjust the output from the driver so the haptic waveform is tailored for that exact actuator. More information on this can be found on the DRV2605 datasheet.

Each of the modes of operation implements the auto calibrate feature differently. Both the Intro Mode and Engineering Mode handle this for you, and you can check the values using the debugging feature in the latter. In Development Mode you must call the function in the program, see the DRV2605 Library in the appendix for more details.

7 Appendices

A. Glossary	21
B. Schematics	23
C. Actuator Table	26
D. Haptic Feedback vs Vibration Alerting	27
E. True Haptics Menu Map	28
F. Effect Table	29
G. DRV2605 Arduino Library Summary	30


A. Glossary

Active Braking	The haptic technique of reversing the polarity of the voltage applied to an ERM to stop the motor quicker. When using an LRA the phase of the drive signal is shifted 180°.
Actuator	Refers to the output component that creates the vibration force, either an ERM or LRA.
Arduino	An open source electronics prototyping platform. Often used to refer to the specific board in use, e.g. “connect to pin D3 on the Arduino”. The Haptic Feedback Evaluation Kit uses an Arduino Uno R3 board.
Auto Calibration	A feature of the DRV2605 that calibrates the driver to compensate for the actuators characteristics, improving haptic performance.
DRV2605	Haptic driver chip from Texas Instruments. Mounted on the Haptic Controller, it stores 123 different haptic effects and sends the drive signal to the actuator after receiving instruction from the Arduino via I2C.
ERM	“Eccentric Rotating Mass” – a type of vibration motor that rotates an unbalanced load to create displacement. http://www.precisionmicrodrives.com/vibrating-vibrator-vibration-motors/pager-motors-erm-motors .
Haptic Controller	The section of the Haptic Feedback Evaluation Kit that acts as the user interface. It contains the capacitive touch buttons for input, an OLED screen for navigation, the Arduino for processing, and the DRV2605 and MOSFET to drive the actuators.
Haptic Feedback	Using advanced vibration patterns to communicate information to the user. The patterns are achieved by using different drive techniques, such as Active Braking and Overdrive, which are normally created using a dedicated haptic driver.
Haptic Feedback Evaluation Kit	The combination of the Haptic Controller and Haptic Grip, creating a complete system for users to learn about haptic feedback and evaluate the performance of different actuators with the DRV2605. By editing the Arduino code it can be used as a development platform for haptic devices.
Haptic Grip	The section of the Haptic Feedback Evaluation Kit that houses 4 Precision Haptic actuators and acts as the output. It is a handheld grip that vibrates when the Haptic Controller sends a drive signal, used both for haptic feedback and vibration alerting.


- I2C** “I-squared-C” or “I-two-C” – a serial digital communication bus used to communicate between the Arduino and the DRV2605. Implemented by the Arduino using the ‘Wire’ library, details on this can be found at Arduino.cc/en/reference/wire.
- IDE** “Integrated Development Environment” – a software application that enables users to create a program. The Arduino IDE allows the programmer to control the Arduino with the source code editor. See Sections 2.3 and 6.5 for more information on using the Arduino IDE.
- LRA** “Linear Resonant Actuator” – a type of vibration actuator that oscillates a magnetic mass on a spring to create displacement. <http://www.precisionmicrodrives.com/vibrating-vibrator-vibration-motors/linear-resonant-actuator-lra-haptic-vibration-motors>.
- Overdrive** The haptic technique of applying the actuators maximum voltage (above the rated voltage) to generate more electromagnetic force, causing the actuator to start quicker.
- MOSFET** A transistor that can act as a switch to control a component that draws a lot of current (e.g. an ERM) with a low current source (e.g. an Arduino). Can support a PWM signal for vibration alerting.
- PWM** “Pulse Width Modulation” – a digital signal of a fixed frequency .The “on time” vs “off time” of a single clock cycle is expressed as a percentage and known as the “duty cycle”. Varying the duty cycle can control the speed (and vibration strength) of an ERM. Implemented by the Arduino using the “analogWrite()” function, details on this can be found at Arduino.cc/en/reference/analogwrite.
- Vibration Alerting** Using basic vibration patterns to communicate information to the user. Typically used to alert the user to an event in a simple “on / off” vibration pattern. Normally created with a PWM signal and a MOSFET, although dedicated drivers are also commonly used for additional benefits.

B. Schematics

Haptic Controller PCB Layout




Top




Bottom


Haptic Shield PCB Layout



Top




Bottom



Precision Microdrives
 haptic_grip-rev1
 26/09/2013 14:58:09
 Sheet: 1/1

Haptic Feedback
 Evaluation Grip




C. Actuator Table

Note there are C10-100s located in both the Haptic Grip and the Haptic Controller for feedback on the touch buttons. The blank cells are for you to record actuators that you want to use with the kit.


Model Number	Type	Typical Normalised Amplitude	Rated / Resonant Vibration Frequency	Rated Voltage	Image	Full Datasheet
305-000	ERM	0.8 G	125 Hz (rated)	1.3 V		Download 305-000 Datasheet
306-109	ERM	3.5 G	200 Hz (rated)	3 V		Download 306-109 Datasheet
308-102	ERM	5.5 G	300 Hz (rated)	4.5 V		Download 308-102 Datasheet
C10-100	LRA	1.4 G	175 Hz (resonant)	2 V (RMS)		Download C10-100 Datasheet

D. Haptic Feedback vs Vibration Alerting

Haptic Feedback **VS** Vibration Alerting






Vibration Profile



Advanced vibration patterns to convey information, simulate clicks & button presses with predefined haptic waveforms.




Simple vibration patterns to notify users of an event. Strong vibrations to catch operator's attention.

Conveys Information

Discrete

Enhanced Experience






Simple & Inexpensive


Discrete


Effective Alert

- Telecommunications
- Auto Dashboards
- Capacitive Touch
- Touchscreens
- Control Sticks
- Videogames




- Scanners and Detectors
- Safety Equipment
- Electronic Tools
- Pagers
- Meters
- GPS






LRA / ERM

\$1.50




Haptics Driver

\$0.70 ~ \$1.20




Host Microcontroller

Budgetary pricing for 10k pcs



Motor IC / MOSFET

\$0.20 ~ \$0.70




ERM / LRA

\$1.25

\$2.20 ~ \$2.70 **Low Cost** **\$1.45 ~ \$1.95**

E. True Haptics Menu Map



F. Effect Table

Effect ID	Waveform	Menu	Effect ID	Waveform	Menu
1	Strong Click 100%	Clicks > Single > Strong	63	Transition Click 6 10%	Clicks > Single > Transition
2	Strong Click 60%	Clicks > Single > Strong	64	Transition Hum 1 100%	Other > Hums
3	Strong Click 30%	Clicks > Single > Strong	65	Transition Hum 2 80%	Other > Hums
4	Sharp Click 100%	Clicks > Single > Tick	66	Transition Hum 3 60%	Other > Hums
5	Sharp Click 60%	Clicks > Single > Tick	67	Transition Hum 4 40%	Other > Hums
6	Sharp Click 30%	Clicks > Single > Tick	68	Transition Hum 5 20%	Other > Hums
7	Soft Bump 100%	Other > Bumps	69	Transition Hum 6 10%	Other > Hums
8	Soft Bump 60%	Other > Bumps	70	Transition Ramp Down Long Smooth 1 100-0%	Ramps > Down > Long
9	Soft Bump 30%	Other > Bumps	71	Transition Ramp Down Long Smooth 2 100-0%	Ramps > Down > Long
10	Double Click 100%	Clicks > Double > Strong	72	Transition Ramp Down Medium Smooth 1 100-0%	Ramps > Down > Medium
11	Double Click 60%	Clicks > Double > Strong	73	Transition Ramp Down Medium Smooth 2 100-0%	Ramps > Down > Medium
12	Triple Click 100%	Clicks > Triple	74	Transition Ramp Down Short Smooth 1 100-0%	Ramps > Down > Strong
13	Soft Fuzz 60%	Other > Buzzes	75	Transition Ramp Down Short Smooth 2 100-0%	Ramps > Down > Strong
14	Strong Buzz 100%	Other > Buzzes	76	Transition Ramp Down Long Sharp 1 100-0%	Ramps > Down > Long
15	750ms Alert	Other > Alerts	77	Transition Ramp Down Long Sharp 2 100-0%	Ramps > Down > Long
16	1000ms Alert	Other > Alerts	78	Transition Ramp Down Medium Sharp 1 100-0%	Ramps > Down > Medium
17	Strong Click 1 100%	Clicks > Single > Strong	79	Transition Ramp Down Medium Sharp 2 100-0%	Ramps > Down > Medium
18	Strong Click 2 80%	Clicks > Single > Strong	80	Transition Ramp Down Short Sharp 1 100-0%	Ramps > Down > Strong
19	Strong Click 3 60%	Clicks > Single > Strong	81	Transition Ramp Down Short Sharp 2 100-0%	Ramps > Down > Strong
20	Strong Click 4 30%	Clicks > Single > Strong	82	Transition Ramp Up Long Smooth 1 0-100%	Ramps > Up > Long
21	Medium Click 1 100%	Clicks > Single > Medium	83	Transition Ramp Up Long Smooth 2 0-100%	Ramps > Up > Long
22	Medium Click 2 80%	Clicks > Single > Medium	84	Transition Ramp Up Medium Smooth 1 0-100%	Ramps > Up > Medium
23	Medium Click 3 60%	Clicks > Single > Medium	85	Transition Ramp Up Medium Smooth 2 0-100%	Ramps > Up > Medium
24	Sharp Tick 1 100%	Clicks > Single > Tick	86	Transition Ramp Up Short Smooth 1 0-100%	Ramps > Up > Short
25	Sharp Tick 2 80%	Clicks > Single > Tick	87	Transition Ramp Up Short Smooth 2 0-100%	Ramps > Up > Short
26	Sharp Tick 3 60%	Clicks > Single > Tick	88	Transition Ramp Up Long Sharp 1 0-100%	Ramps > Up > Long
27	Short Double Click Strong 1 100%	Clicks > Double > Strong	89	Transition Ramp Up Long Sharp 2 0-100%	Ramps > Up > Long
28	Short Double Click Strong 2 80%	Clicks > Double > Strong	90	Transition Ramp Up Medium Sharp 1 0-100%	Ramps > Up > Medium
29	Short Double Click Strong 3 60%	Clicks > Double > Strong	91	Transition Ramp Up Medium Sharp 2 0-100%	Ramps > Up > Medium
30	Short Double Click Strong 4 30%	Clicks > Double > Strong	92	Transition Ramp Up Short Sharp 1 0-100%	Ramps > Up > Short
31	Short Double Click Medium 1 100%	Clicks > Double > Medium	93	Transition Ramp Up Short Sharp 2 0-100%	Ramps > Up > Short
32	Short Double Click Medium 2 80%	Clicks > Double > Medium	94	Transition Ramp Down Long Smooth 1 50-0%	Ramps > Down > Long
33	Short Double Click Medium 3 60%	Clicks > Double > Medium	95	Transition Ramp Down Long Smooth 2 50-0%	Ramps > Down > Long
34	Short Double Sharp Tick 1 100%	Clicks > Double > Tick	96	Transition Ramp Down Medium Smooth 1 50-0%	Ramps > Down > Medium
35	Short Double Sharp Tick 2 80%	Clicks > Double > Tick	97	Transition Ramp Down Medium Smooth 2 50-0%	Ramps > Down > Medium
36	Short Double Sharp Tick 3 60%	Clicks > Double > Tick	98	Transition Ramp Down Short Smooth 1 50-0%	Ramps > Down > Strong
37	Long Double Sharp Click Strong 1 100%	Clicks > Double > Strong	99	Transition Ramp Down Short Smooth 2 50-0%	Ramps > Down > Strong
38	Long Double Sharp Click Strong 2 80%	Clicks > Double > Strong	100	Transition Ramp Down Long Sharp 1 50-0%	Ramps > Down > Long
39	Long Double Sharp Click Strong 3 60%	Clicks > Double > Strong	101	Transition Ramp Down Long Sharp 2 50-0%	Ramps > Down > Long
40	Long Double Sharp Click Strong 4 30%	Clicks > Double > Strong	102	Transition Ramp Down Medium Sharp 1 50-0%	Ramps > Down > Medium
41	Long Double Sharp Click Medium 1 100%	Clicks > Double > Medium	103	Transition Ramp Down Medium Sharp 2 50-0%	Ramps > Down > Medium
42	Long Double Sharp Click Medium 2 80%	Clicks > Double > Medium	104	Transition Ramp Down Short Sharp 1 50-0%	Ramps > Down > Strong
43	Long Double Sharp Click Medium 3 60%	Clicks > Double > Medium	105	Transition Ramp Down Short Sharp 2 50-0%	Ramps > Down > Strong
44	Long Double Sharp Tick 1 100%	Clicks > Double > Tick	106	Transition Ramp Up Long Smooth 1 0-50%	Ramps > Up > Long
45	Long Double Sharp Tick 2 80%	Clicks > Double > Tick	107	Transition Ramp Up Long Smooth 2 0-50%	Ramps > Up > Long
46	Long Double Sharp Tick 3 60%	Clicks > Double > Tick	108	Transition Ramp Up Medium Smooth 1 0-50%	Ramps > Up > Medium
47	Buzz 1 100%	Other > Buzzes	109	Transition Ramp Up Medium Smooth 2 0-50%	Ramps > Up > Medium
48	Buzz 2 80%	Other > Buzzes	110	Transition Ramp Up Short Smooth 1 0-50%	Ramps > Up > Short
49	Buzz 3 60%	Other > Buzzes	111	Transition Ramp Up Short Smooth 2 0-50%	Ramps > Up > Short
50	Buzz 4 40%	Other > Buzzes	112	Transition Ramp Up Long Sharp 1 0-50%	Ramps > Up > Long
51	Buzz 5 20%	Other > Buzzes	113	Transition Ramp Up Long Sharp 2 0-50%	Ramps > Up > Long
52	Pulsing Strong 1 100%	Other > Pulses	114	Transition Ramp Up Medium Sharp 1 0-50%	Ramps > Up > Medium
53	Pulsing Strong 2 80%	Other > Pulses	115	Transition Ramp Up Medium Sharp 2 0-50%	Ramps > Up > Medium
54	Pulsing Medium 1 100%	Other > Pulses	116	Transition Ramp Up Short Sharp 1 0-50%	Ramps > Up > Short
55	Pulsing Medium 2 60%	Other > Pulses	117	Transition Ramp Up Short Sharp 2 0-50%	Ramps > Up > Short
56	Pulsing Sharp 1 100%	Other > Pulses	118	Long Buzz for Programmatic Topping 100%	Other > Buzzes
57	Pulsing Sharp 2 60%	Other > Pulses	119	Smooth Hum 50%	Other > Hums
58	Transition Click 1 100%	Clicks > Single > Transition	120	Smooth Hum 40%	Other > Hums
59	Transition Click 2 80%	Clicks > Single > Transition	121	Smooth Hum 30%	Other > Hums
60	Transition Click 3 60%	Clicks > Single > Transition	122	Smooth Hum 20%	Other > Hums
61	Transition Click 4 40%	Clicks > Single > Transition	123	Smooth Hum 10%	Other > Hums
62	Transition Click 5 20%	Clicks > Single > Transition			

G. DRV2605 Arduino Library Summary


Parent	Notes	Function Syntax	Description	Parameters	Returns
Motor.cpp	<p>Recommended object: Motor motor = Motor(); The Motor object encapsulates DRV2605 functionality and gives a simpler interface to playing vibration alerts and haptic effects. Only one should be instantiated at a time, as demonstrated in the IntroMode and EngineeringMode sketches</p>	selectMotor(motorID);	Selects the output motor on the grip. Required even if using external actuator is being used - autoCalibrate()	motorID: uint8_t	Void
		isCalibrated();	Checks to see if selected actuator has undergone calibration	None	Boolean Value True = calibrated False = not calibrated
		autoCalibrate();	Runs auto calibration on selected motor. selectMotor() must be called first	None	Void
		playVibAlert(waveform , pwr , onTime , offTime);	Plays vibration alert on selected actuator, LRA is not supported so motorID ≠ 3. Implements a continuous loop, use interrupts or edit function to stop.	waveform: uint8_t pwr: uint8_t onTime: uint8_t offTime: uint8_t	Void
		playFullHaptic(library , effect);	Plays haptic effect from DRV2605 on selected actuator. If LRA is selected (motorID = 3) then library 6 will be used	library: uint8_t effect: uint8_t	Void
		getMotorID();	Gets current motorID	None	Int
		isPlaying();	Checks to see if an actuator is playing a haptic effect	None	Boolean Value True = playing False = not playing
		isPlayingVib();	Checks to see if an actuator is playing a vibration alert. Note 'off times' return a true value. Must be called in interrupt	None	Boolean Value True = playing False = not playing
		stopVibAlert();	Stops the vibration alerting being played. Must be called in interrupt	None	Void
getMotorName();	Returns current motor ID product code	None	Char string		
DRV2605.cpp	<p>Recommended object: extern DRV2605 drv2605; The DRV2605 class abstracts away the I2C communications to the DRV2605 chip, providing a streamlined interface for playing effects. Only one DRV2605 object should be instantiated. If using the DRV2605 object from the Motor class use 'extern', as above.</p>	autoCal(ratedVoltage , overdriveClamp , LRA , compensation , backEMF , feedback);	Run the DRV2605's auto-calibration routine on the selected actuator with the values passed in. If auto-calibration is successful (function returns true) the compensation, back EMF and feedback values have been set	ratedVoltage: uint8_t overdriveClamp: uint8_t LRA: boolean compensation: uint8_t* backEMF: uint8_t* feedback: uint8_t*	Boolean value True = successful False = unsuccessful
		playFullHaptic(library , effect , ratedVoltage , overdriveClamp , compensation , backEMF , feedback);	Plays haptic effect from DRV2605 on selected actuator. Pass in compensation, back EMF, and feedback values returned from auto-calibration, or manually adjusted values	library: uint8_t effect: uint8_t ratedVoltage: uint8_t overdriveClamp: uint8_t compensation: uint8_t backEMF: uint8_t feedback: uint8_t	Void
debug.cpp	N/A	freeRAM();	Returns amount of unused RAM space in DRV2605	None	Int

Parameter	Type & Limits	Values	Description
motorID	0 ≤ int ≤ 3	0 = 305-000 1 = 306-109 2 = 308-102 3 = C10-100	Selects the output actuator. Select 3 if using external LRA
waveform	0 ≤ int ≤ 3	0 = Square 1 = Sine 2 = Triangle 3 = Sawtooth	Changes the output waveform for vibration alerts
pwr	0 ≤ int ≤ 100	0% - 100%	The peak output strength of the selected waveform, always goes from 0% to pwr value
onTime	0 ≤ int ≤ 255	Tenths of Seconds	The amount of time the vibration alert vibrates over
offTime	0 ≤ int ≤ 255	Tenths of Seconds	The amount of time between vibration alerts
library	1 ≤ int ≤ 6	1 - 5 = ERM 6 = LRA	The haptic library on the DRV2605 to be used
effect	1 ≤ int ≤ 123	See Effect ID table	The haptic effect on the DRV2605 to be used
ratedVoltage	0 ≤ int ≤ 255	Voltage applied to ERM = ratedVoltage x (5.44 V / 255)	See full DRV2605 datasheet for detailed explanation and calculation of LRA voltage
overdriveClamp	0 ≤ int ≤ 255	Voltage applied to ERM = overdriveClamp x (5.6 V / 255)	Peak voltage allowed in all modes of DRV2605 operation
LRA	bool	True = LRA Mode, False = ERM Mode	Sets bit 7 of register 0x1A, putting the DRV2605 into LRA or ERM mode
compensation	0 ≤ int ≤ 255	Auto Calibration Compensation Coefficient = 1 + compensation / 255	Manually adjusts compensation for resistive losses in the driver
backEMF	0 ≤ int ≤ 255	Auto Calibration Back EMF (V) = (backEMF / 255) x (4.88 V / BEMFGain)	Manually adjusts results for back EMF of the actuator, BEMFGain set by feedback
feedback	int, only specific values valid	N/A	Manually adjusts feedback control register, see full DRV2605 datasheet for details

Pin Mapping

PIN REQUIREMENTS

OLED	3V3, 5V, GND, 5, 8, 10, 11, 13	CAPACITIVE TOUCH	3V3, 5V, GND, A4, A5, 2
HAPTIC GRIP	5V, GND, A0, A1, 6, 7	MOSFET	5V, GND, 6, 7, 9
DRV2605	3V3, 5V, GND, A4, A5, 4, 6, 7, 9		



I2C Addresses

Using 7-bit Addressing

Capacitive Touch Driver MPR121 0x5D

Haptic Driver DRV2605 0x5A